



2010 DYNAPAC CC424HF COMPACTORS

INSPECTION DETAILS

Inspection Type	Marketing
Inspection Form	Standard
Inspection #	10222695
Inspection Status	Completed
Created	08/12/25 12:47:09
Updated	08/12/25 14:18:22
Created By	Calderas, Marco
Inspector	Calderas, Marco
Reviewers	Calderas, Marco
Salesperson	Schultis, Derrick R.
Stock #	E206286
Serial #	10000320L0A008766
SMU / Hours	4,598
Location	Eloy, AZ 85131, United States



FEATURES

General

- Lighting
- ROPS - Open
- VIBRATORY SYSTEM
- WATER SPRAY SYSTEM

Regulatory

- Emissions Level
Engine Tier Rating: 2011 US EPA
and California

CONDITION



Good



Fair



Poor

Approved Repair

GENERAL CONDITION

Body



Frame



General



ET Product Status Report
Download
NO

Machine Starts and is Operable
YES

S.O.S. (All Compartments)
NO

Visible Oil Leaks
NO

GENERAL APPEARANCE

Cab or Canopy



Crankcase Guard / Battery Box



Decals



2

Decals are fade and cracking

Eng. Enclose Hood / Stack



3

Front Frame



Fuel Tank



Right side engine compartment door
latch does not latch (door is tied with
wire to keep shut)

Grab Irons



1

Paint



Radiator Grill & Shroud



Right side grabe handle missing
handle

Paint is scratched and faded

Rear Frame



Steps / Ladder




2

Left rear step is missing lock


CLEANING REQUIRED
NO

SAFETY ITEMS

Back Up Alarm

Back up alarm does not work

Horn


ROPS


Seat Belt / Date

Seat belt is tearing



Parking Brake Functioning
YES
switch is broke



ROPS Certification Plate
YES




Safety Decals In Place
YES

Safety Decals Legible
YES


Safety Locks / Pins
YES

OPERATOR STATION


Armrests

right side arm rest is worn, and left side is worn and will not fold down




Dash Console


Floor Boards / Mats



Gauges


HORIZONTAL SLIDE

seat horizontal slide does not stay in locked position





Hour Meter - OPERATOR STATION


Hydraulic Controls



Interior Plastic / Fabric

plastic interior pieces are dry rotting and cracking




Monitoring Display


Seat Cushions / Suspension / Type

seat cushions are torn, and suspension is loose



Switches

Park brake switch is broke and other switches are faded

Transmission Controls

Boot on hydraulic control is torn



Current O&MM
NO
missing o&mm

Current Parts Manual
NO

Current Safety Manual
NO
missing safety manual

ENGINE

Belts / Pulleys - ENGINE ●● belt is cracked	📷1	Engine Oil Level / Condition ●●●	Engine Supports / Mounts ●● engine mounts have cracks	📷1
Exhaust / Muffler / Stack ●●●		Fuel Injection System ●●●	Intake / Air Filters ●● part of service	📷1
Operating Condition ●●●		Turbocharger / Blower ●●●		
Blow By NO		Emissions Decal Legible YES	📷1	Knocking NO
Oil Leaks NO		Water in Oil YES		

COOLING SYSTEM

Anti-Freeze Level / Color / Condition ●●● red	📷1	Coolers ●●●	Fan ●●●	
Fan Shrouds / Guards ●●●		Hoses / Tubes ●●●	Radiator ●●● radiator is dirty	📷1
Water Pump ●●●				
Compression in Radiator NO		Coolant Leaks NO	Oil in Anti-Freeze NO	
Standard Radiator YES				

ELECTRICAL, STARTING AND CHARGING SYSTEM

Alternator ●●●	Batteries / Cables / Master Disconnect ●●●	Beacon / Strobe ● beacon light does not work	📷1
-------------------	---	--	----

Starter / Type
●●●

Wiring
●●●

Work Lights
●●
left rear work light is not working

1

Signal Lights

NO

TRANSMISSION

Lines / Fittings
●●●

Overall Operating Condition
●●●

Transmission - Forward Shifts
●●●

Transmission - Reverse Shifts
●●●

Leaks
NO

Transmission - Noisy
NO

STEERING

Articulate P & B
●●●

Pivot P & B Trunnions
●●●

Steering Linkage
●●
has movement

1

Steering Valves / Pumps
●●●

Notes - STEERING
right side steering cylinder is wet

2

HYDRAULICS

Hose Lines
●●
clamps for hydraulic lines on right front are missing

1

Propel Motor
●●●

Propel Pump
●●
right front motor is wet

1

Tank
●●●

Vibratory Motor
●●●

Vibratory Pump
●●●

DRUM

Drum Hubs
●●●

DRUM SCRAPER HANDLES
●
right rear handle is bent left fron
handle is loose and bent scraping on
drum has sharp edges

Drum Scrapers
●●
drum scrapers are worn

Drum Surface
●●●

Isolators
●●●
have minor dry Rott

Vibratory System
●●●

Water Dist. Mats
●
water system does not work (i filled
tank to 60% with water) right side tank
lid is cracked



